



STEPBACK

SETBACK

PROPERTY LINE

*Stepback
occurs above a
specified storey*